



FESM-3636

1. Exhaust pipe
2. Governor control rod
3. Choke control rod
4. Clutch housing
5. Support stands FES 142-1
6. Hydraulic oil lines
7. Wooden wedge (2)

8. Using a new gasket and O-rings, install and connect the hydraulic oil lines (6) to the pump and the cylinder block assembly.

9. Install the governor control rod (2).

10. Install the choke control rod (3).

11. Install the exhaust pipe (1).

12. Remove the support stands (5) and the wooden wedges (7).

13. Install the hood and fuel tank assembly. Connect the fuel line to the fuel strainer.

14. Install the headlights and connect the wires to them.

15. Connect the battery ground wire to the battery.