


MAINTENANCE



B-4768 B

Illust. 45
Wiring diagram for starting and lighting.