

INDEX

Description	Page No.	Description	Page No.
Adjustable front axle.....	53, 65	Fan belt.....	27, 28
Air cleaning system.....	28, 29	Farmall Touch-Control system.....	67 to 69
Ammeter.....	6	Filter element.....	15
Antifreeze solutions.....	26	Front axle.....	19
		Front axle, adjustable.....	53, 65
Battery.....	43 to 46	Front wheels.....	16, 51, 53
Battery ignition unit.....	33 to 35	Fuel screen.....	20
Battery testing.....	43	Fuel strainer.....	25
Before starting your new tractor.....	7	Fuel system.....	7, 8
Belt pulley.....	6, 13, 62	Fuel tank.....	7
Brake pedal latch.....	4	Fuse.....	43
Brake pedal lock.....	4		
Brake pedals.....	4	Gearshift lever.....	6
Brakes.....	48	Generator and regulator.....	37, 40
Brakes, locking.....	10	Generator belt.....	28, 38, 41
		Governor.....	5
Cables, battery.....	37	Grease specifications.....	16, 17
Cables, spark plug.....	30, 33		
Carburetor.....	24	Hand cranking the engine.....	8, 9
Carburetor choke lever.....	5	Headlights.....	36
Carburetor fuel line screen.....	24	High clearance attachment.....	66
Choke rod.....	5	Hitching to the tractor.....	49
Clutch.....	47		
Clutch pedal.....	4	Ignition.....	7
Cold weather precautions.....	25	Ignition cables.....	30, 33
Cooling system.....	7, 26 to 28	Ignition switch button.....	5
Crankcase breather.....	14	Instruments and controls.....	4 to 6
Cranking motor.....	8, 9, 42	Introduction.....	2
Cutaway view of tractor.....	22		
Cylinder head gasket.....	46	Lamps.....	53
		Light switch.....	6, 36
Distributor cap, battery ignition.....	34	Lubricating oil and grease specifications....	16, 17
Distributor cap, magneto.....	31	Lubrication.....	14 to 22
Drain plug, engine crankcase.....	19	Lubrication, front wheels.....	16
Drain plug, radiator.....	26	Lubrication guide.....	18 to 22
Drain plug, steering gear housing.....	22		
Drain plug, Touch-Control oil reservoir....	69	Magneto.....	30 to 32
Drain plug, transmission.....	21	Magneto impulse coupling.....	25, 31
Drawbar.....	49, 50	Minor engine service operations.....	46
Driving the tractor.....	10 to 13		
		Oil filter.....	14, 15
Electric starting and lighting.....	36 to 45, 66	Oil pressure indicator.....	5, 14
Engine hour meter.....	66	Oil pump.....	14
Engine serial number.....	2	Operating the engine.....	8
Engine speed control lever.....	5		
Exhaust muffler.....	65		