


## DESCRIPTION

### Instruments and Controls

A variety of special equipment is available for use with the Farmall Cub. The instructions for operating and maintaining the special equipment have been included in the instructions for operating and maintaining the tractor. Disregard the instructions for special equipment not on your tractor.



Illust. 4

Location of controls.

#### Brake Pedals

These pedals are used to stop the tractor, to hold the tractor in a stationary position, or to assist in making sharp turns as outlined below:

To stop the tractor, latch the pedals together so both brakes will operate simultaneously when the pedals are pressed down.

To hold the tractor in a stationary position, latch the pedals together, depress and lock them in this depressed position by using the brake pedal lock.

To assist in making a sharp turn, the pedals must be operated individually, de-

pressing the pedal on the side toward which the turn is to be made.

The brake pedal latch (located behind the left-hand brake pedal) is used to latch both brake pedals together, causing the brakes to operate simultaneously.

The brake pedal lock (*Illusts. 4 and 48B*) is used to lock the brake pedals in the depressed position. This prevents the tractor from moving.

#### Clutch Pedal

This pedal, when depressed all the way, disengages the engine from the transmission.