

1. Nylon sling, FES 138

10. Support the engine and split the tractor by moving the engine forward.

7. Disconnect the wires (5 and 4) to be only starter, requires and light be even to identify the wires (5).

4-4