

Section 8

HYDRAULIC SYSTEM Touch-Control

CONTENTS

	Page
SPECIFICATIONS	8-2
GENERAL	
Cleaning	8-3
Handling of O-Rings	8-4
PRINCIPLES OF OPERATION	8-4
Hand Control and Rockshaft at Rest, Oil Circulating at Low Pressure	8-7
Hand Lever Moved to Lower Implement, Showing Path of Oil to and from Rockshaft Piston	8-8
Hand Lever Moved to Raise Implement, Showing Path of Oil to and from Rockshaft Piston	8-12
REMOVAL	8-14
DISASSEMBLY	
Touch-Control Pump	8-16
Cylinder Block	8-16
INSPECTION AND REPAIR	8-20
REASSEMBLY	8-20
INSTALLATION	8-24
TROUBLE SHOOTING TEST PROCEDURE	
General	8-27
Procedure	8-28
TROUBLE SHOOTING CHART	8-34