1	Control	valve	operating	link
	COIIIIOI	AGIAC	operaring	11111

- 2. Connecting rod pin
- 3. Control valve operating link pin
- 4. Control valve pin
- 5. Control valve operating lever
- 6. Control valve operating lever pin
- 7. Control rod adjustable yoke
- 8. Piston sleeve boot
- 9. Connecting rod bushing
- 10. Connecting rod
- 11. Connecting rod yoke
- 12. Connecting rod yoke seal ring
- 13. Piston sleeve seal rings
- 14. Piston
- 15. Piston head seal ring
- 16. Connecting rod yoke nut
- 17. Connecting rod yoke pin
- 18. Cylinder block assembly
- 19. Set screw
- 20. Control valve seal ring
- 21. Control valve
- 22. Control valve boot
- 23. Filler plug

- 24. Filler plug gasket
- 25. Control valve operating lever stop
- 26. Control valve operating lever stop lock
- 27. Pipe plug
- 28. Relief valve screen
- 29. Relief valve
- 30. Cylinder block cover gasket
- 31. Cylinder block cover
- 32. Orifice plug w/screen
- 33. Cylinder block oil strainer
- 34. Safety valve bushing tension spring
- 35. Safety valve inner bushing seal ring
- 36. Safety valve inner bushing
- 37. Safety valve outer bushing
- 38. Safety valve piston
- 39. Safety valve sleeve
- 40. Safety valve spring
- 41. Pressure regulator check valve spring
- 42. Pressure regulator check valve
- 43. Pressure regulator valve tension spring

- 44. Pressure regulator valve bushing front seal ring
- 45. Pressure regulator valve bushing
- 46. Pressure regulator valve bushing rear seal rina
- 47. Pressure regulator valve piston
- 48. Pressure regulator valve piston seal ring
- 49. Check valve spring
- 50. Check valve
- 51. Check valve bushing inner seal ring
- 52. Check valve inner bushing
- 53. Check valve actuator seal ring
- 54. Check actuator valve
- 55. Check valve bushing outer seal ring (small)
- 56. Check valve bushing outer seal ring (large)
- 57. Check valve outer bushing
- 58. Cylinder head gasket
- 59. Cylinder head

Legend applies to Touch-Control assembly with cylinder block casting number 360 719 R1.