

Probable Cause	Remedy
Engine Does Not Develop Full Power	
1. Distributor: (a) Point gap incorrect (b) Ignition timing incorrect	Readjust point gap. Refer to "Tune-Up", page 1-74. Check and adjust timing. Refer to "Tune-Up", page 1-74.
2. Low voltage to spark plugs caused by defective coil	Replace coil.
3. Fouled spark plugs	Clean plugs and reset the gap. Refer to "Tune-Up", page 1-74.
4. Carburetor: (a) Float level set too low (b) Choke plates partially restricted (c) Restricted throttle linkage	Check float level. Reset if necessary. Reposition choke control linkage. Repair or replace.
5. Insufficient air to engine	Service the air cleaner.
6. Late valve timing	Check and adjust timing. Refer to "Specifications."
7. Air leaks around intake manifold	Tighten manifold or install new gasket if necessary.
8. Exhaust restricted	Remove restriction.
9. Lack of compression	See "Lack of Compression" in this chart.
10. Governor worn out or out of adjustment	Refer to governor section of "Fuel System", Section 2.