


Removal and Installation of Carburetor


Before removing the carburetor from the engine for cleaning, inspection or repair, clean the area and various connecting points to prevent entry of dirt into those parts which remain with the engine.

Failure to perform this simple operation may result in an ultimate condition much worse than that which made the carburetor removal necessary.



Engine Ser. No.
U312389 and below

- | | |
|--------------------------------|----------------------|
| 1. Intake and exhaust manifold | 5. Manifold tubes |
| 2. Governor connecting rod | 6. Carburetor |
| 3. Air cleaner pipe | 7. Fuel line |
| 4. Touch-Control pump | 8. Choke control rod |



Engine Ser. No.
U312390 and above

- | | |
|--------------------------------|------------------------|
| 1. Intake and exhaust manifold | 5. Manifold tubes |
| 2. Governor connecting rod | 6. Carburetor |
| 3. Air cleaner pipe | 7. Choke control cable |
| 4. Touch-Control pump | 8. Fuel line |