



A-26630

Reference numbers only are shown in illustration. Use IH part numbers in ordering.  
Unnumbered parts in the illustrations are the same as corresponding parts shown with numbers.

### TOUCH-CONTROL LEVER, ROD, QUADRANT AND SUPPORT

1	352 045 R11	ROD, CONTROL	501 TO 120338	1
	103 025	NUT, HEX., 5/16-24NF		2
1	354 959 R11	ROD, CONTROL	120339 UP	1
	103 025	NUT, HEX., 5/16-24NF		2
	137 130	PIN, COTTER, 1/16 x 7/16"		1
	103 494	PIN, ROD END, 1/4"		1
2	354 957 R11	SHAFT AND ARM, HAND CONTROL LEVER	120339 UP	1
	Q 1 510	WASHER, PLAIN, 7/16"		1
	114 495	NUT, JAM, HEX., 7/16-20NF		2
3	352 040 R11	LEVER, HAND CONTROL	501 TO 120338	1
	103 372	PIN, COTTER, 3/32 x 1/2"		1
3	350 719 R12	LEVER, HAND CONTROL	120339 UP	1
	142 493	PIN, GROOV, 5/32 x 3/4" (TYPE No. 1)		1
4	350 912 R1	DISC, FRICTION, HAND CONTROL	501 TO 120338	1
4	63 090 D	DISC, FRICTION, HAND CONTROL	120339 UP	1
5	352 039 R1	BRACKET, HAND CONTROL	501 TO 120338	1
	179 847	SCREW, CAP, HEX-HD., 3/8-16NC x 2"		1
	103 321	WASHER, LOCK, 3/8"		1
5	354 960 R1	BRACKET, HAND CONTROL	120339 UP	1
	179 847	SCREW, CAP, HEX-HD., 3/8-16NC x 2"		1
	103 321	WASHER, LOCK, 3/8"		1
6	350 717 R91	INDICATOR, STOP, W/THUMB SCREW (WILL WORK FOR 350 713 R91)		2
7	350 712 R1	QUADRANT, HAND CONTROL		1
	103 024	NUT, HEX., 1/4-28NF		2
	181 311	SCREW, CAP, HEX-HD., 1/4-28NF x 5/8"		2
	103 319	WASHER, LOCK, 1/4"		2
8	352 044 R1	SUPPORT, HAND CONTROL QUADRANT	501 TO 120338	1
8	354 958 R1	SUPPORT, HAND CONTROL QUADRANT	120339 UP	1
9	350 724 R1	SPRING, FRICTION, HAND CONTROL	501 TO 120338	1
9	354 746 R1	SPRING, FRICTION, HAND CONTROL	120339 UP	1
10	351 128 R1	RETAINER, HAND CONTROL FRICTION SPRING	501 TO 120338	2
			120339 UP	1