




ATTACHMENTS



Reference numbers only are shown in illustration. Use I H part numbers in ordering.

PNEUMATIC TIRE PUMP (Schrader) (Special)

NO. REQ'D
A B

KEY TO LETTERS IN CAPTIONS-

A. 39 622 D 8888-CG PNEUMATIC TIRE PUMP, 350 489 R91,
w/ADAPTER (FOR 18 MM THREAD SPARK PLUG HOLE)
(OPTIONAL WITH ENGINE AIR PUMP, 39 604 DA)

B. 350 342 R91 8888-TGK PNEUMATIC TIRE PUMP, 350 489 R91, w/ADAPTERS
(FOR 10, 14, 18 MM, 1/2 AND 7/8" THREAD SPARK
PLUG HOLE)

NO.	PART NO.	DESCRIPTION	A	B
1	42 813 D	2615-D CONNECTOR, PUMP	1	1
2	42 808 D	8888-9 HOSE (4 FT.)	1	1
3	42 809 D	8888-11 GAGE, DIAL	1	1
4	42 806 D	8888-7 GAGE, CONNECTOR	1	1
5	42 807 D	8888-8 HOSE (12 FT.)	1	1
6	62 602 D	8380 CLAMP, HOSE	4	4
7	42 802 D	8888-2 DISC, RUBBER	1	1
8	42 812 D	8888-17 WASHER, FIBRE	1	1
9	42 800 D	8888-1 SHELL, LONG	1	1
10	42 811 D	8888-16 WASHER, RUBBER (IN ADAPTER)	1	1
11	(*) 39 625 D	8888-78 ADAPTER, 7/8", 18 MM		1
11	(*) 39 626 D	8888-18 ADAPTER, 18 MM	1	1
11	(*) 39 627 D	8888-14 ADAPTER, 14 MM		1
11	(*) 350 490 R1	8888-12 ADAPTER, 1/2"		1
11	(*) 350 491 R1	8888-10 ADAPTER, 10 MM		1
12	42 810 D	8888-15 SCREW (FOR ADAPTER)	1	1
13	350 489 R91	8888-G PUMP, TIRE, w/GAGE, ASSEMBLY	1	1
	65 814 D	8954-A ADAPTER, AIR-WATER		1
	350 483 R91	880 MBS-5 CAPS, VALVE (SET OF 5)		1
	140 249 H	4000 MBS-5 CORES, VALVE (SET OF 5)		1
	350 488 R1	9350 GAGE, PRESSURE, TIRE		1
	350 484 R1	3263 TOOL, VALVE REPAIR		1
	350 485 R1	8104 TOOL, VALVE FISHING		1
	350 486 R91	9251 BR VALVE, TIRE, AIR-WATER		1
		(*) - ADAPTERS ARE INTERCHANGEABLE ON EACH OF THE ABOVE ATTACHMENTS		