



A-14702A

Reference numbers only are shown in illustration. Use I H part numbers in ordering.

### SPARK PLUGS, CABLES AND TERMINALS

#### SPARK PLUGS—Normal Service

1	353 976 R91	PLUG, SPARK (CHAMPION No. 15-A)	4
1	353 982 R91	PLUG, SPARK (AC-85-S COM)	4
1	353 991 R91	PLUG, SPARK (AUTO-LITE BT-8)	4

#### SPARK PLUGS—Light or Moderate Service

1	355 261 R91	PLUG, SPARK (CHAMPION C-15)	4
1	353 985 R91	PLUG, SPARK (AC-88-S COM)	4
1	353 992 R91	PLUG, SPARK (AUTO-LITE BT-10)	4

#### SPARK PLUGS—Severe Service

1	353 978 R91	PLUG, SPARK (CHAMPION No. H-17-A)	4
1	353 983 R91	PLUG, SPARK (AC-83-S COM)	4
1	353 990 R91	PLUG, SPARK (AUTO-LITE BT-4)	4

#### SPARK PLUGS—Extremely Severe Service

1	353 977 R91	PLUG, SPARK (CHAMPION No. H-16-A)	4
1	353 986 R91	PLUG, SPARK (AC-81-S COM)	4
1	353 989 R91	PLUG, SPARK (AUTO-LITE BT-3)	4
2	37 762 H	GASKET, SPARK PLUG	4
3	251 426 R1	BRACKET, SPARK PLUG CABLE	1
4	71 198 H	GROMMET, SPARK PLUG CABLE BRACKET	1
5	356 697 R91	PACKAGE, SERVICE, IGNITION CABLE (CONSISTS OF SPARK PLUG CABLE, ASSEMBLY WITH CABLE, 356 686 R91 AND SIX NIPPLES, 251 553 R1) (WILL WORK FOR 351 621 R91 AND 352 946 R91)	1
6	356 686 R91	CABLE, COIL TO DISTRIBUTOR	1
7	251 553 R1	NIPPLE, SPARK PLUG CABLE	4