


## ELECTRICAL SYSTEM



Reference numbers only are shown in illustration. Use I H part numbers in ordering.

### BATTERY IGNITION SWITCH (Special)

1	62 801 DC	SWITCH, BATTERY IGNITION, ASSEMBLY	1
	64 022 H	SCREW, SLOTTED-SPECIAL-HD., CD-PLTD., No. 8-32NC x 5/16"	2
	121 841	WASHER, LOCK, CD-PLTD., No. 8	2
2	8 732 D	KNOB, SWITCH	1
	120 217	WASHER, LOCK, CD-PLTD., No. 10	1
3	56 517 DX	NUT, MOUNTING, SWITCH, W/SEAL	1
	138 553	WASHER, LOCK, INTERNAL TOOTH, CD-PLTD., 9/16"	1
4		SWITCH, MAGNETO IGNITION (ORDER 62 801 DC)	1
	59 109 D	SPACER, IGNITION SWITCH	1