




## ELECTRICAL SYSTEM



B-6188

Reference numbers only are shown in illustration. Use I H part numbers in ordering.  
 Unnumbered parts in the illustrations are the same as corresponding parts shown with numbers.

REF. NO.	I H PART NUMBER	MFR'S. NUMBER	DESCRIPTION	SERIAL NUMBER	No. REQ'D	
					A	B
<b>GENERATOR (Delco-Remy)</b>						
KEY TO LETTERS IN CAPTION -						
A - 354 237 R91 GENERATOR						
B - 45 634 D GENERATOR (FOR TD-14A CRAWLER TRACTOR (LIGHTING ONLY))						
	354 237 R91	1100501	GENERATOR, COMPLETE		1	
	45 634 D	1101355	GENERATOR, COMPLETE			1
1		815018	BOLT, THRU		2	
1		815018	BOLT, THRU			2
		120638	WASHER, LOCK, CD-PLTD., 5/16"		2	2
2		1886496	SCREW, COMMUTATOR END COVER PLATE		3	3
		106496	WASHER, LOCK, No. 8		3	
		1904376	WASHER, LOCK			3
3		820524	PLATE, COVER, COMMUTATOR END FRAME		1	1
4		817220	GASKET, COMMUTATOR END FRAME COVER PLATE		1	1
5		812823	BUSHING, COMMUTATOR END		1	1
6		804076	WICK, OIL, COMMUTATOR END		1	1
7		1913564	OILER, COMMUTATOR END		1	
		1880635	OILER, COMMUTATOR END			1
8		816315	PLUG, OIL WICK, COMMUTATOR END		1	1

Always give GENERATOR NUMBER when ordering Parts.