

INDEX TO UNITS

Description	List Page	Illust. Page	Description	List Page	Illust. Page
ENGINE					
Camshaft and related parts.....	9	8	Differential.....	72	72
Carburetor—International (3/4" updraft).....	25	24	Drawbar.....	96	96
Connecting rods.....	12	12	Fender.....	87	87
Cover, front.....	9	8	Final drive.....	89	88
Crank, starting.....	12	12	Fuel pipe.....	63	62
Crankcase.....	9	8	Gear shifter mechanism.....	75	74
Crankshaft and related parts.....	12	12	Governor controls.....	67	67
Cylinder head.....	16	16	Hood.....	63	62
Fan.....	17	17	Lubricator, hand.....	97, 98	97, 98
Filter, lubricating oil.....	19	19	Package, assorted gasket.....	100	
Governor and connections.....	21	21	Package, decal.....	101	
Indicator, oil pressure.....	9	8	Package, overhaul and improvement.....	100	
Manifold.....	20	20	Platform.....	94	94
Oil pump screen and tube.....	15	15	Radiator.....	63	62
Oil pump body.....	9	8	Radiator screen.....	63	62
Pan, crankcase oil.....	15	15	Rim, rear wheel.....	92	92
Pipe, exhaust.....	20	20	Seat and platform.....	94	94
Pistons.....	12	12	Steering knuckle.....	79	78
Service engine.....	7		Steering mechanism.....	83	82
Valves.....	9	8	Strainer, fuel.....	65	65
			Support, hood and fuel tank.....	63	62
			Tank, fuel.....	63	62
			Tools.....	99	99
			Tool box.....	99	99
			Transmission.....	75	74
			Transmission case.....	72	72
			Transmission gear shifter mechanism.....	75	74
			Wheel, front.....	77	77
			Wheel, rear.....	92	92
ELECTRICAL SYSTEM			HYDRAULIC SYSTEM		
Battery box (Special).....	33	33	Lever, rod, quadrant and support.....	109	109
Battery ignition unit (Special).....	34	34	Pump, drive gear and manifold tubes.....	107	107
Brakets, headlight or rear light (Special).....	49	49	Rockshaft and support.....	108	108
Combination rear light and tail light attachment (Special).....	51, 53	51, 53	Touch Control—		
Distributor, battery ignition (Special).....	36	36	Cylinder block, cylinder head, piston, connecting rod, regulator valve, check valves and connections.....	103	102
Generator (Delco-Remy).....	42	42	ATTACHMENTS—Special		
Generator (Delco-Remy) and connections.....	40	40	Axle, front, adjustable.....	79	78
Headlight and rear light (Guide) (Special).....	49	49	Belt pulley.....	111	110
Lighting and starting attachment (Special).....	57	56	Cylinder head, high altitude.....	16	16
Magneto—International type J-4.....	29	28	Exhaust muffler.....	118	118
Motor, cranking (Delco-Remy).....	47	46	Hour meter, engine.....	119	119
Motor, cranking, lever and pull rod (Special).....	45	45	Power take-off.....	111	110
Plugs, spark, cables and terminals.....	27	27	Pump, pneumatic tire (Enginair).....	114	114
Switch and cable, magneto ignition.....	32	32	Pump, pneumatic tire (Schrader).....	115	115
Switch, battery ignition (Special).....	38	38	Spark arrester.....	118	118
Switch, lighting (Delco-Remy) (Special).....	39	39	Swinging drawbar.....	96	96
			Weights—front wheel.....	116	116
			—rear wheel.....	117	117
CHASSIS					
Air cleaner and connections.....	66	66			
Axle, front.....	79	78			
Brakes, foot.....	85	85			
Clutch (Atwood).....	68	68			
Clutch (Rockford).....	69	69			
Clutch housing, controls and connections.....	70	70			

NUMERICAL INDEX..... Page 121

SUFFIX LETTER CODE..... Page 120