



CHASSIS

REF. NO.	PART NUMBER	DESCRIPTION	SERIAL NUMBER	NO. REQ'D
FRONT AXLE AND STEERING KNUCKLE — Continued				
16	356 718 R91	KNUCKLE AND ARM, STEERING, R.H., ASSEMBLY (WILL WORK FOR 350 766 R11)	501 TO 138484	1
		(COMPOSED OF -		
		1 ARM 356 712 R1		
		1 KEY 218 211		
		1 KNUCKLE 356 714 R91		
		1 NUT 103 027		
		1 SCREW 181 406		
		1 WASHER 103 322		
	103 027	NUT, HEX., LIGHT, 7/16-20NF		1
	181 406	SCREW, CAP, HEX-HD., 7/16-20NF x 2"		1
	103 322	WASHER, LOCK, MEDIUM, 7/16"		1
16	356 714 R91	KNUCKLE, STEERING, w/SEAL, 350 769 R91 AND WASHER, 350 768 R1	138485 UP	2
17	350 768 R1	WASHER, FELT, FRONT WHEEL		2
18	350 769 R91	OIL SEAL, FRONT WHEEL		2
19	350 770 R91	BEARING, INNER, FRONT WHEEL (TIMKEN) (CUP, 350 772 R1 AND CONE, 350 771 R91)		
		(OPTIONAL WITH 352 378 R91 OR 353 511 R92)		2
19	352 378 R91	BEARING, INNER, FRONT WHEEL (BOWER) (CUP, 352 392 R1 AND CONE, 352 385 R91)		
		(OPTIONAL WITH 350 770 R91 OR 353 511 R92)		2
19	353 511 R92	BEARING, INNER, FRONT WHEEL (TYSON) (CUP, 353 527 R1 AND CONE, 353 519 R92)		
		(OPTIONAL WITH 350 770 R91 OR 352 378 R91)		2
20	350 773 R91	BEARING, OUTER, FRONT WHEEL (TIMKEN) (CUP, 350 774 R1 AND CONE, 350 774 R91)		
		(OPTIONAL WITH 352 379 R91 OR 353 512 R92)		2
20	352 379 R91	BEARING, OUTER, FRDNT WHEEL (BOWER) (CUP, 352 393 R1 AND CONE, 352 386 R91)		
		(OPTIONAL WITH 350 773 R91 OR 353 512 R92)		2
20	353 512 R92	BEARING, OUTER, FRONT WHEEL (TYSON) (CUP, 353 528 R1 AND CONE, 353 520 R92)		
		(OPTIONAL WITH 350 773 R91 OR 352 379 R91)		2
21	350 771 R91	CONE, FRDNT WHEEL INNER BEARING (TIMKEN No. 15580)		
		(OPTIONAL WITH 352 385 R91 OR 353 519 R92)		2
21	352 385 R91	CONE, FRONT WHEEL INNER BEARING (BOWER BT 15580)		
		(OPTIONAL WITH 350 771 R91 OR 353 519 R92)		2
21	353 519 R92	CONE, FRONT WHEEL INNER BEARING (TYSON No. 15580)		
		(OPTIONAL WITH 350 771 R91 OR 352 385 R91)		2
22	350 772 R1	CUP, FRONT WHEEL INNER BEARING (TIMKEN No. 15520)		
		(OPTIONAL WITH 352 392 R1 OR 353 527 R1)		2
22	352 392 R1	CUP, FRONT WHEEL INNER BEARING (BOWER BT 15520)		
		(OPTIONAL WITH 350 772 R1 OR 353 527 R1)		2
22	353 527 R1	CUP, FRONT WHEEL INNER BEARING (TYSON No. 15520)		
		(OPTIONAL WITH 350 772 R1 OR 352 392 R1)		2
23	350 775 R1	CUP, FRONT WHEEL OUTER BEARING (TIMKEN No. 17520)		
		(OPTIONAL WITH 352 393 R1 OR 353 528 R1)		2
23	352 393 R1	CUP, FRONT WHEEL OUTER BEARING (BOWER BT 17520)		
		(OPTIONAL WITH 350 775 R1 OR 353 528 R1)		2
23	353 528 R1	CUP, FRONT WHEEL OUTER BEARING (TYSON No. 17520)		
		(OPTIONAL WITH 350 775 R1 OR 352 393 R1)		2
24	350 774 R91	CONE, FRONT WHEEL OUTER BEARING (TIMKEN No. 17580)		
		(OPTIONAL WITH 352 386 R91 OR 353 520 R92)		2
24	352 386 R91	CONE, FRONT WHEEL OUTER BEARING (BOWER BT 17580)		
		(OPTIONAL WITH 350 774 R91 OR 353 520 R92)		2
24	353 520 R92	CONE, FRONT WHEEL OUTER BEARING (TYSON No. 17580)		
		(OPTIONAL WITH 350 774 R91 OR 352 386 R91)		2