



### CHASSIS

REF. NO.	PART NUMBER	DESCRIPTION	SERIAL NUMBER	NO. REQ'D
<b>SEAT AND PLATFORM — Continued</b>				
9	351 883 R11	TUBE, SEAT SUPPORT		1
	179 925	SCREW, CAP, HEX-HD., 5/8-11NC x 1-1/4"		2
	103 325	WASHER, LOCK, 5/8"		2
10	351 879 R1	SHOCK ABSORBER, SEAT POST		1
11	351 013 R1	CLIP, STARTING CRANK		2
	171 573	SCREW, TAPPING, SLOTTED-RD-HD., No. 10-32NF x 1/4"		2
12	351 051 R11	PLATFORM		1
	220 065	NUT, HEX., 5/16-18NC		3
	179 812	SCREW, CAP, HEX HEAD, 5/16-18NC x 1/2"		2
	179 814	SCREW, CAP, HEX HEAD, 5/16-18NC x 5/8"		4
	179 816	SCREW, CAP, HEX HEAD, 5/16-18NC x 3/4"		1
	179 837	SCREW, CAP, HEX HEAD, 3/8-16NC x 3/4"		3
	103 320	WASHER, LOCK, 5/16"		7
	103 321	WASHER, LOCK, 3/8"		3
	351 440 R92	ATTACHMENT, DETACHABLE SEAT PAD (SPECIAL) (CONSISTS OF SEAT PAD, 351 438 R92)		1
	357 518 R91	ATTACHMENT, DELUXE UPHOLSTERED SEAT (WILL WORK FOR 354 155 R91)		1
	351 960 R93	ATTACHMENT, UPHOLSTERED SEAT (MACHINE ATTACHMENT)		1
	353 065 R1	EYELET, FASTENING, DETACHABLE SEAT PAD		1
	353 064 R1	NUT, SPEED		1
	351 438 R92	PAD, DETACHABLE SEAT		1