Lubrication Guide

Tractors with battery ignition

Oil level gauge on left side of engine

Both sides

Both sides

Both sides

Front axle detail

B-3044A

Illust. 18

Side view of tractor.



Illust. 18A

Crankcase oil filler.



Illust. 18B

Air cleaner oil cup.



Illust. 18C

Front axle.