ENGINE



Reference numbers only are shown in illustration. Use I H part numbers in ordering.
Unnumbered parts in the illustrations are the same as corresponding parts shown with numbers.

MANIFOLD AND EXHAUST PIPE

1	350 960 R1	PIPE, EXHAUST	1
2	251 233 R1	GASKET, EXHAUST AND INTAKE MANIFOLD	2
3	251 232 R1	MANIFOLD, EXHAUST AND INTAKE	1
	103 865	PLUG, PIPE, SQ-HD., 1/8"	1
4	251 176 R1	NUT, EXHAUST AND INTAKE MANIFOLD STUD	4
5	251 236 R1	STUD, CARBURETOR	2
	103 024	NUT, HEX., 1/4-28NF	2
	103 319	WASHER, LOCK, 1/4"	2